

VHHH AD 2.22 FLIGHT PROCEDURES**1 ATC Clearance, Engine Start-Up and Push-back Procedures**

- 1.1 All aircraft, other than helicopters and locally based light aircraft, shall obtain an ATC clearance prior to engine start. Pilots are to inform Hong Kong Ground/Delivery, as appropriate, of the following:
- callsign,
 - parking stand number/location,
 - Identifier of the latest ATIS received unless it has been included in the RCD (Request for Departure Clearance Downlink) message via data link,
 - proposed flight level if it is different from the filed flight plan, and
 - when applicable, special requirements (eg request for another departure runway or inability to comply with SID climb profile).

Additionally, departures for destinations in China routeing via BEKOL (A461) shall contact Hong Kong Delivery 15 minutes before estimated off-block time (EOBT) to obtain advance notification of any flow control restriction that may affect the flight.

Approved aircraft planning to fly the Radius-to-Fix SID (ATENA1E/F, LOGAN1E/F, RASSE1E/F, SKATE1E/F or TITAN1E/F) shall make request when obtaining ATC clearance, using recommended phraseology – “Request Radius-to-Fix SID”. Aircraft using 2-way Pre-Departure Clearance (PDC) data-link service shall make such voice request prior to sending ‘Request for Departure Clearance Downlink’ (RCD) message.

- 1.2 A 2-way Pre-Departure Clearance (PDC) data-link service is available to approved operators. Pilots should send a ‘Request for Departure Clearance Downlink’ (RCD) message to ATC not more than 20 minutes prior to EOBT. If the CLD message is not received within 5 minutes or there is any problem with data link exchanges, the pilot shall inform Hong Kong Delivery on frequency 129.9 MHz.
- 1.3 Pilots not participating in the PDC service shall contact Hong Kong Delivery on frequency 129.9 MHz, 5 minutes prior to start to put their ATC clearance on request. Upon receipt of the ATC clearance the pilot shall read back the following information:
- aircraft callsign,
 - destination,
 - route,
 - SID and
 - transponder code.
- 1.4 Pilots shall comply with instructions issued by Hong Kong Delivery regarding when to contact the relevant Hong Kong Ground frequency.
- 1.5 Once an ATC clearance has been received, unless there is a specific time restriction included in the clearance, any delay in being ready to push-back, start engines or taxi may result in the clearance being cancelled.
- 1.6 Pilots shall contact Hong Kong Ground on frequency 122.55 MHz except when notified it is sectorised in which case pilots shall contact:
- Hong Kong Ground (North) for North and West Aprons on frequency 121.6 MHz;
 - Hong Kong Ground (South) for South, Cargo and Business Aviation Aprons on frequency 122.55 MHz.
- 1.7 Aircraft should not commence start-up, push-back, or any other manoeuvre on the apron, unless they have obtained approval from Hong Kong Ground.

- 1.8 Prior to requesting for push back or taxi from a parking stand, pilots of aircraft equipped with a 'weight-on-wheel' switch must ensure the transponder is operating (on 'AUTO' or 'XPNDR', and not 'STDBY' or 'OFF') and the assigned Mode A code is selected. Aircraft with Mode S transponder capable of reporting Aircraft Identification should have its identification in the ICAO flight plan format entered via FMS or Control Panel.
- 1.9 The majority of parking stands have two standard push-back procedures, Push-back BLUE and Push-back RED. The normal push-back procedure is to the taxi lane abeam the adjacent parking stand, but where this would result in the aircraft entering a critical area the push-back is extended to a Tug Stop Point clear of the critical area. A limited number of parking stands have a Push-back/Tow-forward procedure, Push-back GREEN. (The push-back procedures for each parking stand are shown on pages AD2-99A to AD2-99C for passenger aprons, AD2-99D for the cargo apron and AD2-99E for the maintenance and west cargo apron.)
- 1.10 Under certain traffic conditions it may be necessary for Hong Kong Ground to issue non-standard push-back instructions to expedite the flow of traffic. Pilots will be issued a 'non-standard push-back' to a defined location and direction.
- 1.11 Pilots shall ensure that the push-back colour code or non-standard push-back instructions issued by Hong Kong Ground are accurately relayed to their ground crew before push-back or engine start commences.
- 1.12 There is a restriction to the starting of engines for aircraft in parking stands S103, S108 and W123. If aircraft in these stands are required to push-back through 180°, only one engine shall be started during the push-back, other engines shall only be started when the push-back manoeuvre has been completed.
- 1.13 When known conditions exist which necessitate that engine start-up is carried out in the parking stand prior to the commencement of push-back, or greater than idle engine thrust will be required during engine start, (e.g. cross-bleed start procedure), the pilot shall advise Hong Kong Ground of the fact when engine start or push-back clearance is requested.
- 1.14 Whilst push-back procedure is being conducted it is essential for safety reasons that communication contact is maintained between pilot and ground engineer in charge. ATC clearance will not normally be issued to aircraft whilst being pushed back, unless the pilot so requests.
- 1.15 To avoid delay to other traffic using the apron aircraft should be ready to taxi as soon as the push-back manoeuvre and engine start procedure are completed. The standard push-back for stands N68 and N70 is onto TWY B. Therefore to avoid delays to other traffic it is essential that the aircraft should be ready to taxi as soon as the push-back manoeuvre is complete. If aircraft are unable to comply with these procedures pilots shall immediately inform Hong Kong Ground in order that alternative taxi instructions may be issued to other traffic.
- 1.16 Pilots are reminded that they should always use minimum power when starting engines or manoeuvring within the apron area. It is especially important when commencing to taxi that break-away thrust is kept to an absolute minimum and then reduced to idle thrust as soon as practicable.

2 Standard Instrument Departures (SIDs)

2.1 GENERAL

2.1.1 Due to the proximity of the FIR boundary to the west, pilots departing RWY 25L or RWY 25R are advised to maintain a careful cross-check of aircraft position after passing PRAWN. In the event of any weather avoidance manoeuvre, permission must be obtained from ATC prior to making any turn away from the prescribed departure track.

2.2 RNP 1 REQUIREMENT

2.2.1 RNP 1 SIDs have been implemented in Hong Kong TMA. (See pages AD2-97 for details of the SID procedures). All aircraft departing HKIA, other than those specified in GEN 1.5 para 3.5.2.4 shall be equipped with appropriate systems and approved by the relevant State of Registry in accordance with ICAO RNP 1 standard. Carriage of a certified GNSS receiver is mandatory.

2.2.2 See GEN 1.5 para 3.5.2 for details of RNP 1 requirement and the Exemption Policy.

2.2.3 *Contingency Procedures.*

2.2.3.1 The Contingency Procedures are only available for flights exempted from RNP 1 requirement as specified in GEN 1.5 para 3.5.2.5.

2.2.3.2 *Failure of RNP 1 capability before departure at HKIA.* In case of failure or degradation of the RNP 1 system which is detected before departure at HKIA and it is not practicable to effect a repair, the aircraft concerned should be permitted to depart. For this purpose, the flight would be exempted under the category “Maintenance or delivery flights” (See GEN 1.5 para 3.5.2.5).

2.2.3.3 *Failure of RNP 1 capability whilst airborne.* In the event that PBN performance ceases to comply with the requirements for RNP 1, pilots must notify ATC with the phraseology “**UNABLE RNP 1 [DUE TO (reason)]**” as soon as possible. Dependent upon the nature of the reported system failure or degradation, continued operation with the current ATC clearance may be possible in many circumstances. When this cannot be achieved, ATC assistance would be provided as necessary.

2.2.3.4 All contingency procedures are direct overlays of the tracks of the RNP 1 procedure with the same SID designator. Pilots conducting the contingency procedures shall refer to and observe all other instructions and requirements (i.e. level and speed restrictions, terrain clearance, etc.) specified in the corresponding RNP 1 procedure charts. ATC assistance may also be provided when necessary.

2.2.3.5 Hong Kong SID Contingency Procedures for aircraft with exemption from RNP 1 requirement:

Hong Kong SID	Contingency Procedures
ATENA 2A (RWY 07R)	Track 074°M to PORPA (ISR DME 7.0 NM, or crossing LKC DVOR RDL 112). At PORPA turn right track direct to RAMEN and then turn left to COLEY. From COLEY turn left direct to ATENA. After ATENA turn left to BEKOL.
ATENA 2C (RWY 07L)	Track 074°M to SMT DVOR. Depart SMT DVOR on RDL 086 to ROVER (SMT DME 2.6 NM, or crossing LKC DVOR RDL 108). At ROVER turn right track direct to RAMEN and then turn left to COLEY. From COLEY turn left direct to ATENA. After ATENA turn left to BEKOL.
BEKOL 3A (RWY 07R)	Track 074°M to PORPA (ISR DME 7.0 NM, or crossing LKC DVOR RDL 112). At PORPA turn right to intercept TD DVOR RDL 297 to TD DVOR. From TD DVOR turn left direct to ATENA then turn left direct to BEKOL. If TD DVOR is not available, at PORPA turn right to track 117°M, request radar vectors to BEKOL.
BEKOL 3C (RWY 07L)	Track 074°M to SMT DVOR. Depart SMT DVOR on RDL 086 to ROVER (SMT DME 2.6 NM, or crossing LKC DVOR RDL 108). At ROVER turn right to intercept TD DVOR RDL 297 to TD DVOR. From TD DVOR turn left direct to ATENA then turn left direct to BEKOL. If TD DVOR is not available, at ROVER turn right to track 117°M, request radar vectors to BEKOL.
BEKOL 2B (RWY 25L)	Track 254°M to PRAWN (IFL DME 7.0 NM, or crossing LKC DVOR RDL 215). At PRAWN turn left track 185°M to intercept NLG DVOR RDL 155 at RUMSY. From RUMSY turn left direct to TUNNA then turn left direct to SAMON then turn left direct to BEKOL. If NLG DVOR is not available, at PRAWN turn left to track 185°M, request radar vectors to TUNNA.
BEKOL 2D (RWY 25R)	Track 254°M to ITFR DME 3.0 NM. At ITFR DME 3.0 NM track 243°M to PRAWN (ITFR DME 7.2 NM, or crossing LKC DVOR RDL 215). At PRAWN turn left track 185°M to intercept NLG DVOR RDL 155 at RUMSY. From RUMSY turn left direct to TUNNA then turn left direct to SAMON then turn left direct to BEKOL. If NLG DVOR is not available, at PRAWN turn left to track 185°M, request radar vectors to TUNNA.

Hong Kong SID	Contingency Procedures
LAKES 3A (RWY 07R)	Track 074°M to PORPA (ISR DME 7.0 NM, or crossing LKC DVOR RDL 112). At PORPA turn right to intercept TD DVOR RDL 297 to TD DVOR. From TD DVOR track direct to SHELY then LAKES. If TD DVOR is not available, at PORPA turn right to track 117°M, request radar vectors to SHELY then LAKES.
LAKES 3C (RWY 07L)	Track 074°M to SMT DVOR. Depart SMT DVOR on RDL 086 to ROVER (SMT DME 2.6 NM, or crossing LKC DVOR RDL 108). At ROVER turn right to intercept TD DVOR RDL 297 to TD DVOR. From TD DVOR track direct to SHELY then LAKES. If TD DVOR is not available, at ROVER turn right to track 117°M, request radar vectors to SHELY then LAKES.
LAKES 2B (RWY 25L)	Track 254°M to PRAWN (IFL DME 7.0 NM, or crossing LKC DVOR RDL 215). At PRAWN turn left track 185°M to intercept NLG DVOR RDL 155 at RUMSY. From RUMSY turn left direct to TUNNA then turn left direct to TROUT then turn left direct to LAKES. If NLG DVOR is not available, at PRAWN turn left to track 185°M, request radar vectors to TUNNA.
LAKES 2D (RWY 25R)	Track 254°M to ITFR DME 3.0 NM. At ITFR DME 3.0 NM track 243°M to PRAWN (ITFR DME 7.2 NM, or crossing LKC DVOR RDL 215). At PRAWN turn left track 185°M to intercept NLG DVOR RDL 155 at RUMSY. From RUMSY turn left direct to TUNNA then turn left direct to TROUT then turn left direct to LAKES. If NLG DVOR is not available, at PRAWN turn left to track 185°M, request radar vectors to TUNNA.
LOGAN 3A (RWY 07R)	Track 074°M to PORPA (ISR DME 7.0 NM, or crossing LKC DVOR RDL 112). At PORPA turn right track direct to RAMEN then turn left to LAKES. From LAKES turn left direct to LOGAN.
LOGAN 3C (RWY 07L)	Track 074°M to SMT DVOR. Depart SMT DVOR on RDL 086 to ROVER (SMT DME 2.6 NM, or crossing LKC DVOR RDL 108). At ROVER turn right track direct to RAMEN then turn left to LAKES. From LAKES turn left direct to LOGAN.
OCEAN 2A (RWY 07R)	Track 074°M to PORPA (ISR DME 7.0 NM, or crossing LKC DVOR RDL 112). At PORPA turn right to intercept TD DVOR RDL 297 to TD DVOR. From TD DVOR turn right direct to OCEAN. If TD DVOR is not available, at PORPA turn right to track 117°M, request radar vectors to OCEAN.

Hong Kong SID	Contingency Procedures
OCEAN 2C (RWY 07L)	Track 074°M to SMT DVOR. Depart SMT DVOR on RDL 086 to ROVER (SMT DME 2.6 NM, or crossing LKC DVOR RDL 108). At ROVER turn right to intercept TD DVOR RDL 297 to TD DVOR. From TD DVOR turn right direct to OCEAN. If TD DVOR is not available, at ROVER turn right to track 117°M, request radar vectors to OCEAN.
OCEAN 2B (RWY 25L)	Track 254°M to PRAWN (IFL DME 7.0 NM, or crossing LKC DVOR RDL 215). At PRAWN turn left track 185°M to intercept NLG DVOR RDL 155 at RUMSY. From RUMSY turn left direct to TUNNA then turn left direct to TROUT and then to OCEAN. If NLG DVOR is not available, at PRAWN turn left to track 185°M, request radar vectors to TUNNA.
OCEAN 2D (RWY 25R)	Track 254°M to ITFR DME 3.0 NM. At ITFR DME 3.0 NM track 243°M to PRAWN (ITFR DME 7.2 NM, or crossing LKC DVOR RDL 215). At PRAWN turn left track 185°M to intercept NLG DVOR RDL 155 at RUMSY. From RUMSY turn left direct to TUNNA then turn left direct to TROUT and then to OCEAN. If NLG DVOR is not available, at PRAWN turn left to track 185°M, request radar vectors to TUNNA.
PECAN 1A (RWY 07R)	Track 074°M to PORPA (ISR DME 7.0 NM, or crossing LKC DVOR RDL 112). At PORPA turn right track direct to RAMEN and then turn right to BREAM. From BREAM track direct to TITAN and PECAN.
PECAN 1C (RWY 07L)	Track 074°M to SMT DVOR. Depart SMT DVOR on RDL 086 to ROVER (SMT DME 2.6 NM, or crossing LKC DVOR RDL 108). At ROVER turn right track direct to RAMEN and then turn right to BREAM. From BREAM track direct to TITAN and PECAN.
PECAN 1B (RWY 25L)	Track 254°M to PRAWN (IFL DME 7.0 NM, or crossing LKC DVOR RDL 215). At PRAWN turn left track 185°M to intercept NLG DVOR RDL 155 at RUMSY. From RUMSY turn left direct to TUNNA then turn left to TITAN then turn right to PECAN. If NLG DVOR is not available, at PRAWN turn left to track 185°M, request radar vectors to TUNNA.

Hong Kong SID	Contingency Procedures
PECAN 1D (RWY 25R)	Track 254°M to ITFR DME 3.0 NM. At ITFR DME 3.0 NM track 243°M to PRAWN (ITFR DME 7.2 NM, or crossing LKC DVOR RDL 215). At PRAWN turn left track 185°M to intercept NLG DVOR RDL 155 at RUMSY. From RUMSY turn left direct to TUNNA then turn left to TITAN then turn right to PECAN. If NLG DVOR is not available, at PRAWN turn left to track 185°M, request radar vectors to TUNNA.
RASSE 3A (RWY 07R)	Track 074°M to PORPA (ISR DME 7.0 NM, or crossing LKC DVOR RDL 112). At PORPA turn right track direct to RAMEN and then turn left to OCEAN. From OCEAN turn left direct to RASSE.
RASSE 3C (RWY 07L)	Track 074°M to SMT DVOR. Depart SMT DVOR on RDL 086 to ROVER (SMT DME 2.6 NM, or crossing LKC DVOR RDL 108). At ROVER turn right track direct to RAMEN and then turn left to OCEAN. From OCEAN turn left direct to RASSE.
SKATE 3A (RWY 07R)	Track 074°M to PORPA (ISR DME 7.0 NM, or crossing LKC DVOR RDL 112). At PORPA turn right track direct to RAMEN and then turn left to OCEAN. From OCEAN turn right direct to SKATE.
SKATE 3C (RWY 07L)	Track 074°M to SMT DVOR. Depart SMT DVOR on RDL 086 to ROVER (SMT DME 2.6 NM, or crossing LKC DVOR RDL 108). At ROVER turn right track direct to RAMEN and then turn left to OCEAN. From OCEAN turn right direct to SKATE.

2.3 TERRAIN CLEARANCE

- 2.3.1 To maintain terrain clearance on the appropriate SID the following procedures must be applied to, except in the radius-to-fix SID (ATENA1E/F, LOGAN1E/F, RASSE1E/F, SKATE1E/F and TITAN1E/F) or when directed by ATC.

Runway	Flyover Point	Rate of Climb (under normal operating conditions)
RWY 07L	Do not turn right before passing ROVER	4.1% or 250 ft/NM until passing 1 400 ft
RWY 07R	Do not turn right before passing PORPA	4.9% or 298 ft/NM until passing 1 400 ft
RWY 25L/25R	Do not turn left before passing PRAWN	3.3% or 201 ft/NM

2.4 DEPARTURE SPEED REQUIREMENT

- 2.4.1 To comply with the speed requirement, crossing PORPA (RWY07R)/ ROVER (RWY07L) or PRAWN (RWY25L/R) at 180 KIAS or greater, it is recommended that the Noise Abatement Departure Procedure 2 (NADP 2) (see VHHH AD2.21 for details) or the manufacturer's recommended procedure be used.

2.4.2 Pilots shall inform ATC prior to entering the runway if they will not be able to comply with the departure speed requirement due to aircraft performance limitations or other factors.

2.5 CLIMB REQUIREMENT

2.5.1 To ensure separation of SID routes from STAR routes, aircraft on LAKES B/D or OCEAN B/D SIDs must cross TROUT at or above FL 140. Pilots unable to comply with this requirement must inform ATC as soon as possible so that alternative action can be taken.

2.5.2 To avoid confliction with traffic in the Guangzhou FIR, aircraft on BEKOL SIDs must cross BEKOL at 4 800 m or above. Track distance from take-off to BEKOL is approximately 48 NM. Pilots unable to comply with this requirement must inform Hong Kong ATC prior to departure.

2.6 LOSS OF COMMUNICATION

2.6.1 In the event of a loss of communication aircraft shall comply with the last acknowledged clearance up to the next reporting point/waypoint in the SID/Transition procedure listed in para.5.2, then climb to the flight planned cruising level and follow the SID/Transition track to the TMA exit point.

3 Terminal Transition Routes

3.1 Within the Hong Kong TMA a number of Terminal Transition Routes are established. Operators departing from Hong Kong International Airport shall flight plan via the relevant Terminal Transition Route until exiting the Hong Kong TMA to join the appropriate ATS route. (See ENR 3.1 table 2 on page ENR 3.1-6 to 3.1-12 and chart page AD 2-85.)

4 SID Navigation Aids

Navaid	Frequency	Co-ordinates
CH DVOR	112.3 MHz	22 13 10.35 N 114 01 48.20 E
CH DME	CH 70X	22 13 10.35 N 114 01 48.20 E
LC NDB	390 kHz	22 17 43 N 113 53 43 E
NLG DVOR	117.7 MHz	22 31 54 N 113 33 48 E
NLG DME	CH 124X	22 31 54 N 113 33 48 E
SMT DVOR	114.8 MHz	22 20 15.43 N 113 58 55.46 E
SMT DME	CH 95X	22 20 15.43 N 113 58 55.46 E
TD DVOR	116.1 MHz	22 14 52.42 N 114 17 35.30 E
TD DME	CH 108X	22 14 52.42 N 114 17 35.30 E

5 SID Locations

- 5.1 SID FLYOVER WAYPOINTS (Note: PORPA and ROVER are **flyby** waypoints in the following radius-to-fix SIDs – ATENA1E/F, LOGAN1E/F, RASSE1E/F, SKATE1E/F and TITAN1E/F.)

Flyover Waypoint	Co-ordinates	Cross Reference from Navaid
RW07L (RWY 07L DER)	22 19 21.08N 113 56 02.35E	IZSL ILS DME 2.0 NM SMT RDL 254/DME 2.8 NM
RW25R (RWY 25R DER)	22 18 34.27N 113 53 37.06E	ITFR ILS DME 2.0 NM SMT RDL 254/DME 5.2 NM
PORPA	22 20 09.10N 114 01 16.30E	ISR ILS DME 7.0 NM LKC RDL 112/DME 8.1 NM
PRAWN	22 16 05.40N 113 48 40.10E	IFL ILS DME 7.0 NM SMT RDL 249/DME 10.4 NM
ROVER	22 20 35.58N 114 01 39.12E	IZSL ILS DME 7.3 NM SMT RDL 086/DME 2.6 NM

5.2. SID REPORTING POINTS / FLYBY WAYPOINTS

Reporting Point / Flyby Waypoint	Co-ordinates		Cross Reference from Navaid
ALLEY	21 05 11.2N	113 47 09.5E	CH RDL 194 / DME 69.1 NM TD RDL 205 / DME 75.0 NM
ATENA	22 24 39.85N	114 23 11.88E	CH RDL 061 / DME 22.9 NM TD RDL 031 / DME 11.1 NM
BEKOL	22 32 36.00N	114 08 00.00E	CH RDL 020 / DME 20.2 NM TD RDL 336 / DME 19.8 NM
BREAM	21 46 46.00N	114 03 28.00E	CH RDL 180 / DME 26.4 NM TD RDL 208 / DME 30.9 NM
COLEY	22 06 41.03N	114 18 37.63E	CH RDL 114 / DME 16.9 NM TD RDL 176 / DME 8.2 NM
DONKI	20 32 58.0N	112 09 10.1E	CH RDL 230 / DME 145.0 NM TD RDL 233 / DME 157.1 NM
LAKES	21 58 41.30N	114 54 38.60E	CH RDL 109 / DME 51.1 NM TD RDL 118 / DME 38.0 NM
LEMON	20 56 16.6N	114 00 05.1E	CH RDL 184 / DME 76.6 NM TD RDL 195 / DME 80.0 NM
LOGAN	21 59 16.17N	115 16 08.46E	CH RDL 104 / DME 70.4 NM TD RDL 109 / DME 56.6 NM
OCEAN	21 48 43.00N	114 48 48.00E	CH RDL 122 / DME 50.0 NM TD RDL 135 / DME 39.0 NM
PECAN	21 26 20.2N	114 02 05.6E	CH RDL 183 / DME 46.7 NM TD RDL 200 / DME 50.5 NM
PORSH	22 17 40.38N	114 05 03.56E	PBN Waypoint
RAMEN	22 09 39.22N	114 05 09.89E	CH RDL 141 / DME 4.7 NM TD RDL 249 / DME 12.6 NM
RASSE	21 47 34.50N	115 19 49.10E	CH RDL 112 / DME 76.9 NM TD RDL 118 / DME 63.9 NM
ROBBE	22 17 59.70N	114 05 10.78E	PBN Waypoint
ROVER	22 20 35.58N	114 01 39.12E	PBN Waypoint
RUMSY	22 04 56.94N	113 48 16.79E	CH RDL 240 / DME 15.0 NM TD RDL 253 / DME 28.9 NM
SAMON	21 54 23.73N	114 12 32.95E	CH RDL 155 / DME 21.2 NM TD RDL 196 / DME 20.9 NM
SHELY	22 05 26.65N	114 39 13.94E	TD RDL 118 / DME 22.2 NM
SKATE	21 31 55.00N	115 08 40.00E	CH RDL 126 / DME 74.5 NM TD RDL 135 / DME 64.0 NM
SURFA	19 18 51.0N	112 44 11.2E	CH RDL 206 / DME 188.8 NM TD RDL 210 / DME 196.5 NM
TITAN	21 40 27.4N	114 03 02.5E	CH RDL 181 / DME 32.6 NM TD RDL 205 / DME 36.9 NM
TROUT	21 47 54.87N	114 16 12.74E	CH RDL 155 / DME 28.5 NM TD RDL 186 / DME 26.9 NM
TUNNA	21 47 25.00N	113 57 54.00E	CH RDL 191 / DME 25.9 NM TD RDL 217 / DME 32.9 NM NLG RDL 155 / DME 49.7 NM

6. Hong Kong International Airport SIDs**6.1 RUNWAY 07 SIDS**

SID	Runway	Remarks
BEKOL _n A	RWY 07R	Between 1501-2300 UTC expect ATENA _n A
BEKOL _n C	RWY 07L	Between 1501-2300 UTC expect ATENA _n C
LAKES _n A	RWY 07R	Between 1501-2300 UTC expect LOGAN _n A
LAKES _n C	RWY 07L	Between 1501-2300 UTC expect LOGAN _n C
OCEAN _n A	RWY 07R	Between 1501-2300 UTC expect RASSE _n A or SKATE _n A
OCEAN _n C	RWY 07L	Between 1501-2300 UTC expect RASSE _n C or SKATE _n C
PECAN _n A	RWY 07R	May be used H24
PECAN _n C	RWY 07L	

6.2 RUNWAY 07 NOISE MITIGATING SIDS

SID	Runway	Remarks
ATENA _n A	RWY 07R	Normally for use between 1501-2300 UTC
ATENA _n C	RWY 07L	
LOGAN _n A	RWY 07R	
LOGAN _n C	RWY 07L	
RASSE _n A	RWY 07R	
RASSE _n C	RWY 07L	
SKATE _n A	RWY 07R	
SKATE _n C	RWY 07L	
ATENA _n E	RWY 07R	Normally for use between 1501-2300 UTC Radius-to-fix (RF) leg is required
ATENA _n F	RWY 07L	
LOGAN _n E	RWY 07R	
LOGAN _n F	RWY 07L	
RASSE _n E	RWY 07R	
RASSE _n F	RWY 07L	
SKATE _n E	RWY 07R	
SKATE _n F	RWY 07L	
TITAN _n E	RWY 07R	
TITAN _n F	RWY 07L	

6.3 RUNWAY 25 SIDS

SID	Runway	Remarks
BEKOL _n B	RWY 25L	May be used H24
BEKOL _n D	RWY 25R	
LAKES _n B	RWY 25L	
LAKES _n D	RWY 25R	
OCEAN _n B	RWY 25L	
OCEAN _n D	RWY 25R	
PECAN _n B	RWY 25L	
PECAN _n D	RWY 25R	

7. Standard Instrument Arrivals (STARs)

7.1 RNP 1 REQUIREMENT

7.1.1 RNP 1 STARs have been implemented in Hong Kong TMA. (See pages AD2-98 for details of the STAR procedures). All aircraft arriving HKIA, other than those specified in GEN 1.5 para 3.5.2.5, shall be equipped with appropriate systems and approved by the relevant State of Registry in accordance with ICAO RNP 1 standard. Carriage of a certified GNSS receiver is mandatory. (see GEN 1.5 para 3.5.2 on page GEN 1.5-2).

7.1.2 See GEN 1.5 para 3.5.2 for details of RNP 1 requirement and the Exemption Policy.

7.1.3 *Contingency Procedures.*

7.1.3.1 The Contingency Procedures are only available for flights exempted from RNP 1 requirement as specified in GEN 1.5 para 3.5.2.5.

7.1.3.2 *Failure of RNP 1 capability whilst airborne.* In the event that PBN performance ceases to comply with the requirements for RNP 1, pilots must notify ATC with the phraseology “**UNABLE RNP 1 [DUE TO (reason)]**” as soon as possible. Dependent upon the nature of the reported system failure or degradation, continued operation with the current ATC clearance may be possible in many circumstances. When this cannot be achieved, ATC assistance would be provided as necessary.

7.1.3.3 All contingency procedures are direct overlays of the tracks of the RNP 1 procedure with the same STAR designator. Pilots conducting the contingency procedures shall refer to and observe all other instructions and requirements (i.e. level and speed restrictions, terrain clearance, etc.) specified in the corresponding RNP 1 procedure charts. ATC assistance may also be provided when necessary.

7.1.3.4 Hong Kong STAR Contingency Procedures for aircraft with exemption from RNP 1 requirement:

Hong Kong STAR	Contingency Procedures
ABBEY 3A (RWY 07L/R)	From ABBEY proceed direct to MUSEL then TAMAR. From TAMAR proceed direct to TD DVOR then GUAVA (TD R251 / D14 NM). From GUAVA proceed direct to SOKOE (TD R251 / D27 NM) then LIMES. Expect ILS approach. Descend as directed by ATC. IF TD DVOR is not available From MUSEL proceed direct to TAMAR then reporting point TD. From reporting point TD proceed direct to GUAVA then SOKOE. From SOKOE proceed direct to LIMES. Descend as directed by ATC.
ABBEY 2B (RWY 25L/R)	From ABBEY proceed direct to MUSEL then TAMAR. From TAMAR proceed direct to TD DVOR. Expect ILS approach. Descend as directed by ATC. IF TD DVOR is not available From MUSEL proceed direct to TAMAR then reporting point TD. Descend as directed by ATC.
BETTY 2A (RWY 07L/R)	From BETTY proceed direct to MANGO then GUAVA (TD R251 / D14 NM). From GUAVA proceed direct to SOKOE (TD R251 / D27 NM) then LIMES. Expect ILS approach. Descend as directed by ATC. If TD DVOR is not available From MANGO proceed direct to GUAVA then SOKOE. From SOKOE proceed direct to LIMES. Descend as directed by ATC.
BETTY 2B (RWY 25L/R)	From BETTY proceed direct to MANGO then TD DVOR. Expect ILS approach. Descend as directed by ATC. If TD DVOR is not available From MANGO proceed direct to reporting point TD. Descend as directed by ATC.
CANTO 3A (RWY 07L/R)	From CANTO proceed direct to MURRY then SILVA. From SILVA turn left to LIMES. Expect ILS approach. Descend as directed by ATC.
CANTO 2B (RWY 25L/R)	From CANTO proceed direct to MURRY then GOODI. From GOODI proceed direct to MONTY then turn left to TD DVOR. Expect ILS approach. Descend as directed by ATC. If TD DVOR is not available From MONTY turn left direct to reporting point TD. Descend as directed by ATC.
SIERA 7A (RWY 07L/R)	From SIERA proceed direct to CANTO. From CANTO turn left to MURRY then SILVA. From SILVA turn left to LIMES. Expect ILS approach. Descend as directed by ATC.

Hong Kong STAR	Contingency Procedures
SIERA 7C (RWY 07L/R)	From SIERA proceed direct to BORDA and then turn left to ROCCA. From ROCCA proceed to CANTO, then MURRY then SILVA. From SILVA turn left to LIMES. Expect ILS approach. Descend as directed by ATC.
SIERA 6B (RWY 25L/R)	From SIERA proceed direct to CANTO. From CANTO turn left to MURRY then GOODI. From GOODI proceed direct to MONTY then turn left to TD DVOR. Expect ILS approach. Descend as directed by ATC. If TD DVOR is not available From MONTY turn left direct to reporting point TD. Descend as directed by ATC.
SIERA 6D (RWY 25L/R)	From SIERA proceed direct to BORDA and then turn left to ROCCA. From ROCCA proceed to CANTO, then MURRY then GOODI. From GOODI proceed direct to MONTY then turn left to TD DVOR. Expect ILS approach. Descend as directed by ATC. If TD DVOR is not available From MONTY turn left direct to reporting point TD. Descend as directed by ATC.

7.2 LOSS OF COMMUNICATION

7.2.1 In the event of a loss of communication:

- a) if a STAR clearance has been issued and acknowledged, aircraft shall comply with the descent planning profile and the STAR track to TD/ LIMES as appropriate, join the relevant holding pattern and descend to 4 500ft, then carry out the ILS approach;
- b) if a STAR clearance has not been issued or acknowledged, aircraft shall proceed in accordance with the STAR procedure appropriate for the ATS route and landing direction, (arrivals from SIERA should proceed in accordance with SIERA _nA or SIERA _nB STAR as appropriate), at TD/ LIMES as appropriate, join the relevant holding pattern and descend to 4 500 ft, then carry out the ILS approach.

7.3 UNSERVICEABILITY OF AIRCRAFT EQUIPMENT OR GROUND EQUIPMENT

- ### 7.3.1 Pilots shall inform ATC if they are unable to comply with the STAR procedure due to unserviceability of aircraft equipment or ground equipment and request radar assistance.

7.4 STAR COMMENCEMENT AND TERMINATION POINTS

- ### 7.4.1 Except for SIERA STARs, Hong Kong STARs commence from ABBEY, BETTY or CANTO and terminate at the Initial Approach Fix (IAF) (e.g. TD DVOR (RWY 25) or LIMES (RWY 07) as appropriate).
- ### 7.4.2 While the SIERA STARs commence directly from the TMA boundary point SIERA, other STARs are connected to the TMA boundary points by Terminal Transition Routes (TTR). (See ENR 3.1 table 2 on page ENR 3.1-6 to 3.1-11 and chart page AD2-87)

8. STAR Navigation Aids

Navaid	Frequency	Co-ordinates
CH DVOR	112.3 MHz	22 13 10.35N 114 01 48.20E
CH DME	CH70X	22 13 10.35N 114 01 48.20E
TD DVOR	116.1 MHz	22 14 52.42N 114 17 35.30E
TD DME	CH108X	22 14 52.42N 114 17 35.30E

9. STAR and TTR Significant Points

Significant Point	Co-ordinates	Cross Reference from Navaid
* ABBEY	22 16 11.00N 114 55 25.92E	TD RDL 091/DME 35.1 NM CH RDL 090/DME 49.8 NM
* BETTY	21 29 10.8 N 114 33 31.9 E	TD RDL 165/DME 47.9 NM CH RDL 149/DME 52.8 NM
BORDA	21 41 32.4N 113 24 29.0E	TD RDL 239/DME 59.5 NM CH RDL 231/DME 46.9 NM
* CANTO	21 39 02.6N 113 42 25.1E	TD RDL 226/DME 48.4 NM CH RDL 211/DME 38.5 NM
CARSO	19 00 00.0 N 114 42 37.8 E	TD RDL 176/DME 195.6NM CH RDL 172/DME 196.2 NM
CYBER	20 50 49.6 N 114 33 10.6 E	TD RDL 173/DME 85.0 NM CH RDL 163/DME 87.1 NM
DOTMI	22 43 06N 116 10 06E	TD RDL 078/DME 107.9 NM CH RDL 079/DME 122.5 NM
DOVAR	20 51 38.9 N 115 07 00.9 E	TD RDL 154/DME 94.9 NM CH RDL 146/DME 101.5 NM
ELATO	22 20 00N 117 30 00E	TD RDL 091/DME 178.5 NM CH RDL 090/DME 193.2 NM
FISHA	22 16 57.64N 115 20 11.61E	TD RDL 091/DME 58.1 NM CH RDL 090/DME 72.8 NM
GAMBA	21 19 08.1N 112 55 36.2E	TD RDL 237/DME 94.4 NM CH RDL 232/DME 81.8 NM
GOODI	22 04 09.9N 113 59 48.6E	TD RDL 240/DME 19.7NM CH RDL 195/DME 9.2 NM

Significant Point	Co-ordinates	Cross Reference from Navaid
# GUAVA	22 09 36.1N 114 03 36.3E	TD RDL 251/DME 14.0 NM CH RDL 158/DME 3.9 NM
HOCKY	20 35 49.4N 114 34 28.5E	TD RDL 174/DME 99.9 NM CH RDL 166/DME 101.7 NM
IDOSI	19 00 00N 112 30 00E	TD RDL 211/DME 218.8 NM CH RDL 206/DME 210.8 NM
# LIMES	22 06 25.60 N 113 46 32.60 E	NLG RDL 157/DME 28.0 NM CH RDL 248/DME 15.7 NM
MAGOG	22 17 46 N 115 49 30 E	CH RDL 090/DME 100.0 NM
MANGO	21 36 49.0N 114 30 53.0E	TD RDL 165/DME 39.9 NM CH RDL 146/DME 45.2 NM
MAPLE	21 22 26.8N 113 05 42.8E	TD RDL 235/DME 84.9 NM CH RDL 229/DME 72.7 NM
MONTY	22 10 06.3N 114 19 15.7E	TD RDL 165/DME 5.0 NM CH RDL 104/DME 16.5 NM
MURRY	21 45 28.4N 113 48 42.0E	TD RDL 226/DME 39.7 NM CH RDL 207/DME 30.2 NM
MUSEL	22 15 53.99N 114 46 52.13E	TD RDL 091/DME 27.2 NM
NOMAN	20 00 00N 116 40 18E	TD RDL 138/DME 189.4 NM CH RDL 134/DME 198.9 NM
RAMUS	20 15 39.1 N 115 21 05.9 E	TD RDL 156/DME 132.8 NM CH RDL 151/DME 138.6 NM
ROCCA	21 31 55.4N 113 34 51.4E	TD RDL 226/DME 58.4 NM CH RDL 215/DME 48.1 NM
SABNO	18 59 06N 115 50 42E	TD RDL 159/DME 213.7 NM CH RDL 155/DME 218.7 NM
* SIERA	21 59 12N 113 33 12E	TD RDL 252/DME 44.1 NM CH RDL 245/DME 30.0 NM
SIKOU	20 50 36N 111 30 00E	TD RDL 245/DME 177.4 NM CH RDL 243/DME 163.7 NM
SILVA	21 51 04.5N 113 54 10.9E	TD RDL 226/DME 32.2 NM CH RDL 201/DME 23.1 NM
SOKOE	22 04 41.2 N 113 50 38.1 E	TD RDL 251/DME 27.0 NM
SONNY	21 01 03.7 N 115 03 18.8 E	TD RDL 153/DME 85.0 NM CH RDL 144/DME 91.9 NM
TAMAR	22 15 21N 114 30 37E	TD RDL 091/DME 12.1 NM
# TD	22 14 52.42N 114 17 35.30E	

- * **STAR commencement point**
- # **IAF**

(Pages AD 2-41 to AD 2-44 and para 10 to 17 reserved)

INTENTIONALLY

LEFT

BLANK

18. Instrument Landing System (ILS) - General

- 18.1 RWY 07L, RWY 07R and RWY 25L ILS are equipped for CAT II landings. RWY 25R ILS is equipped for CAT IIIA landings. Operators must obtain approval prior to conducting CAT II/IIIA operations, (see page AD.1.1-3). Pilots wishing to make an ILS CAT II/IIIA approach shall notify Approach Control on initial contact.
- 18.2 The standard instrument approach at Hong Kong International Airport is the ILS approach procedure. Therefore the Arrival ATIS will not include the type of approach to be expected when the ILS approach procedure is in use. (When the ILS is not available, the type of approach to be expected will be specified in the Arrival ATIS.)
- 18.3 No marker beacons are provided. DME equivalents for Outer Marker Fix (OMF) and Middle Marker Fix (MMF) with glidepath reference altitudes are established.
- 18.4 Due to the proximity of the FIR boundary to the west, pilots carrying out RWY 07L or RWY 07R ILS approach are advised to maintain a careful cross-check of aircraft position after passing the initial approach fix LIMES by the use of appropriate navigational aids to ensure the aircraft remains on the prescribed track. In the event of any weather avoidance manoeuvre, permission must be obtained from ATC prior to making any turn away from the prescribed track.
- 18.5 The ILS approach procedures include specific speed restrictions. These speed restrictions are applicable to aircraft that are radar vectored to join the initial or intermediate approach as well as aircraft commencing the approach from the initial approach fix, (RWY 07L/07R IAF LIMES, RWY 25L/25R IAF TD DVOR). Pilots unable to comply with these speed restrictions should inform ATC prior to commencing the approach so that alternative action can be taken.
- 18.6 Pilots are warned that during ILS CAT I operations RWY 07R and RWY 25L GP signals may be liable to interference from aircraft taxiing in the vicinity of the GP aerial. Pilots should therefore closely monitor their ILS approach profile and rate of descent.
- 18.7 Due to terrain some of the ILS LOC and GP signals at Hong Kong International Airport do not have the standard protected areas. The standard ICAO protected areas for ILS signal coverage are:
- LOC signal 17 NM within 35° each side of the course line and 25 NM within 10° each side of the course line;
 - GP signal 10 NM within 8° each side of the centreline.

Pilots are reminded that use of the ILS signals outside of the following coverage areas may lead to false capture or reverse sense indications:

RWY	LOC Coverage Area	GP Coverage Area
RWY 07L	Standard left of LOC course	Standard left and right of RWY centreline
	17 NM within 28° right of LOC course and 25 NM within 10° right of the LOC course	

RWY	LOC Coverage Area	GP Coverage Area
RWY 07R	17 NM within 25° left of LOC course and 25 NM within 10° left of the LOC course	Standard left and right of RWY centreline
	17 NM within 19° right of LOC course and 25 NM within 10° right of the LOC course	
RWY 25L	17 NM within 28° left of LOC course and 25 NM within 10° left of the LOC course	15 NM within 7° left of RWY centreline
	Standard right of LOC course	Standard right of RWY centreline
RWY 25R	Standard left of LOC course	Standard left of RWY centreline
	Between 20 NM - 25 NM within 4° right of LOC course below 5 500 ft	15 NM within 6° right of RWY centreline

- 18.8 If ground based navigational aids are not available, ATC will provide an alternative clearance or give radar assistance.

19. RWY 07L ILS and LOC Approach

19.1 Requests to proceed direct from a point within the TMA to LIMES for an ILS approach RWY 07L may be approved subject to traffic. →

19.2 See AD2-93A, B, C and D for procedure details. |

20. RWY 07L VOR Approach

20.1 Requests to proceed direct from a point within the TMA to LIMES for a VOR approach RWY 07L may be approved subject to traffic.

20.2 See AD2-93E and F for procedure details. →

21. RWY 07R ILS and LOC Approach

21.1 Requests to proceed direct from a point within the TMA to LIMES for an ILS approach RWY 07R may be approved subject to traffic.

21.2 Pilots are warned that RWY 07R GP signals may be liable to interference from aircraft taxiing in the vicinity of the GP aerial. Pilots should therefore closely monitor their ILS approach profile and rate of descent. →

21.3 See AD2-91A, B, C and D for procedure details. |

22. RWY 25L ILS and LOC Approach

22.1 Requests to proceed direct from a point within the TMA to MIRRS for an ILS approach RWY 25L may be approved subject to traffic.

22.2 Pilots are warned that RWY 25L GP signals may be liable to interference from aircraft taxiing in the vicinity of the GP aerial. Pilots should therefore closely monitor their ILS approach profile and rate of descent.

22.3 See AD2-92 A, B, C and D for procedure Details. →

23. RWY 25R ILS and LOC Approach

23.1 Requests to proceed direct from a point within the TMA to PLOVE for an ILS approach RWY 25R may be approved subject to traffic. →

23.2 See AD2-94, B, C and D for procedure details. |

24. RWY 25R VOR Approach

24.1 See AD2-94E and F for procedure details. →

25 RNP AR APCH

25.1 RNP AR APCH RWY 07 via north of HKIA

25.1.1 RNP AR APCH procedures for RWY 07L/R, namely, RNAV_(RNP) RWY 07L and RNAV_(RNP) RWY 07R are available to provide alternative approach paths for arriving aircraft to approach from the north of HKIA on a left hand circuit (North Circuit).

25.1.2 The procedures are provided to cater for circumstances when weather precludes the conduct of approach from the south. Therefore, requests for these procedures in other situations would not normally be entertained.

25.1.3 Should the weather situation mentioned in para. 25.1.2 arise, pilots of authorized airline operators, who are qualified and wish to fly the RNP AR APCH procedures, shall make a request to Hong Kong Air Traffic control (ATC) unit. Subject to prevailing traffic situation, ATC may consider granting the approval of such request.

25.1.4 Special Authorization from Hong Kong CAD is required to conduct RNP AR APCH in Hong Kong.

25.2 RNP AR APCH Operational Approval

25.2.1 Refer to Hong Kong AIC 14/13.

26 Procedures for Local Flights in Hong Kong Aerodrome Traffic Zone (ATZ) and Control Zone (CTR) Zones

26.1 GENERAL

26.1.1 Local flights operating in the Aerodrome Traffic Zone (ATZ) are under the control of Hong Kong Aerodrome Control. During parallel runway operations the ATZ is split into two sectors. The Dividing line is mid-way between the two runways - the north runway (RWY 07L/25R) is under the control of AMC North, operating on frequency 118.2 MHz, call-sign 'Hong Kong Tower North', and the south runway (RWY 07R/25L) is under the control of AMC South, operating on frequency 118.4 MHz, call-sign 'Hong Kong Tower South'.

26.1.2 Non-IFR flights within the CTR Zones (see chart page AD 2-102), are under the control of Hong Kong Zone Control operating on frequency 120.6 MHz, call sign 'Hong Kong Zone'.

26.1.3 Flights within the CTR above 2 000 ft AMSL are under the control of Hong Kong Approach Control on frequency 119.1 MHz or Departure Control on frequency 123.8 MHz.

26.1.4 To enhance flight safety, it is recommended that all local operators display landing lights whilst entering, leaving or operating within the ATZ or CTR Zones.

26.2 VERTICAL LIMITS AND ALTITUDE RESTRICTIONS

26.2.1 The vertical limits are:

- a) ATZ surface up to 2 000 ft AAL;
- b) CTR Zones surface up to 2 000 ft AMSL (subject to paras. 26.2.2 and 26.2.3 below).

26.2.2 In the following CTR Zones ATC will apply an altitude restriction dependant on the runway in use at Hong Kong International Airport:

CTR Zone	RWY in Use	Altitude Restriction
South Outer Zone	RWY 07L/R	500 ft
Delta Zone		As instructed by ATC
Island Zone routes :		
Green Island – Ma Wan Corridor		1 000 ft
Green Island – Silvermine		800 ft
Green Island – Cheung Chau		1 000 ft
Green Island – Lamma		1 000 ft
Green Island – west of Star Ferry	1 000 ft	
East of Star Ferry	1 500 ft	
South Outer Zone	RWY 25L/R	1 200 ft
Delta Zone		As instructed by ATC

26.2.3 In addition, flights requesting to operate in Ma Wan Zone above 500 ft AMSL, Tuen Mun Zone north of Line B above 1 000ft AMSL and Lantau Zone above 2 000ft AMSL, including operations at landing sites above these levels, are subject to specific approval from Hong Kong Zone.

26.3 ATZ AND CTR ZONES ENTRY AND EXIT ROUTES

26.3.1 Subject to ATC approval, pilots shall normally comply with the following standard exit and entry routes and altitudes within the ATZ and CTR Zones (see chart AD2-103):

Radio Callsign	Route Direction	Routeing
East Pass	In/Out	Entering/Leaving Island Zone from/to UCARA Port Shelter Single engine aircraft not permitted
Fan Lau (See Note 1)	North/South East/West	Transiting to/from West Lantau Corridor and Island Zone and Transiting to/from Island Zone and Delta Zone
Gold Coast Corridor (See Note 2)	East/West (one direction at a time)	Transiting Ma Wan Zone between Pearl Island and Brothers Point Upper limit 500ft AMSL Width 0.5NM. Helicopters only
Lei Yue Mun	In/Out	Entering/Leaving Island Zone from/to Waglan Zone

		Inbound to CTR 1 500ft AMSL Outbound from CTR not above 1 000ft AMSL (If weather precludes use of 1 500 ft AMSL inbound, operations shall be restricted to one direction at a time)
Ma Wan Corridor (See Note 2 and 3)	In/Out	Transiting from/to Ma Wan Zone and Island Zone Upper limit 1000ft AMSL
Pak Mong	In/Out	Entering/Leaving ATZ for Ma Wan Zone
Pillar Point	In/Out	Entering/Leaving ATZ for Tuen Mun Zone
Sha Chau	In/Out	Entering/Leaving ATZ for Tuen Mun Zone
Sham Shek	In/Out (one direction at a time)	Entering/Leaving ATZ for West Lantau Corridor
Sha Tin Pass	In/Out	Entering/Leaving Island Zone from/to UCARA New Town Single engine aircraft not permitted
Silvermine	In/Out	Entering/Leaving ATZ and Ma Wan Zone for Lantau Zone Helicopters only
South Pass	In/Out	Transiting Island Zone between Hong Kong South and Victoria Harbour Fixed wing aircraft and single engine helicopters not permitted
Toll Plaza Route (see Note 2, 4 and 5)	East/West (one direction at a time)	Transiting from/to North Lantau Expressway and Kap Shui Mun. Upper limit 800ft AMSL for twin engine aircraft, 1 000 ft AMSL for single engine aircraft
Toll Plaza Crossing	North/South	Between Yam O and Brothers Point Upper limit 500ft AMSL
Tung Chung Pass	In/Out	Entering/Leaving ATZ for Lantau Zone Helicopters only Inbound to ATZ 2 000ft AMSL Outbound from ATZ not above 1 500ft AMSL (If weather precludes use of 2 000ft AMSL inbound, operations shall be restricted to one direction at a time)
West Lantau Corridor (See Note 6)	North/South	Transiting from/to Tai O and Fan Lau Width 1NM between Fan Lau and Tai O, 0.5NM at Sham Shek Upper limit 500ft AMSL north of Peaked Hill (Kai Yet Kok), 1 000ft AMSL south of Peaked Hill (Kai Yet Kok)

- Note 1: Pilots should note traffic information on non-IFR helicopters operating between Macao and Hong Kong routeing south of Lantau Island.
- Note 2: Operators should limit their requests for use of these routes to essential operations only due to the close proximity of the Hong Kong International Airport approach/departure routes.
- Note 3: Silvermine is the primary route for helicopters to transit between ATZ, Ma Wan Zone and Lantau Zone.
- Note 4: Helicopters with underslung load are not permitted.
- Note 5: The use of this route will be subject to ATC clearance - traffic at 1 000ft AMSL is not separated from RWY 25 arrivals or RWY 07 departures. Aircraft from Island Zone awaiting ATC clearance to transit the Toll Plaza route may hold to the west of Tsing Yi Island not above 500 ft AMSL, remaining clear of VHR12.
- Note 6: Radio coverage on the western coast of Lantau may be intermittent, pilots should note relevant traffic information prior to entering the West Lantau Corridor.

27 Helicopter Departure and Arrival Procedures

27.1 DEPARTURE FROM GFS/BAC TO PAK MONG OR SILVERMINE

27.1.1 **Kilo East Departure** Subject to ATC approval and when traffic permits, lift off from TWY K in an easterly direction, then turn south between TWY Z3 and the Fire Station to follow the airport coastline until abeam the western roundabout on Chun Wan Road (see chart AD 2-106, Route A).

27.1.2 **For departure in other directions** Turn south as soon as practicable after lift off and track along the airport coastline until abeam the western roundabout on Chun Wan Road.

27.1.3 From abeam the western roundabout, helicopters should keep 1000 m south of the runway extended centreline, may track direct to Silvermine or Pak Mong at not above 1500 ft AMSL (see chart AD 2-106, Route B).

27.1.4 During Special VFR operations pilots are required to report passing AFFC (radio c/s 'Freight Centre') to Hong Kong Tower when departing from the airport.

27.1.5 Helicopters departing from sites at the airport that require to cross the south runway, e.g. HAECO maintenance area, shall initially route as directed by ATC.

27.2 ARRIVALS FROM PAK MONG OR SILVERMINE TO GFS/BAC

27.2.1 Follow the reciprocal of para 27.1.3 above to AFFC at not above 1500 ft AMSL. From AFFC follow ATC instructions to commence an approach. ATC approval must be obtained before overflying or landing on TWY K.

27.2.2 Helicopters operating to sites on the airport that require to cross the south runway, e.g. Temporary Parking Apron, shall initially comply with para 27.2.1 above then the final approach route will be as directed by ATC.

27.2.3 If holding is required, follow ATC instructions and comply with para 27.3 below.

27.3 HELICOPTER HOLDING PROCEDURES

27.3.1 The following holding procedures shall be used by helicopters awaiting clearance for landing at the airport.

Location	VFR/SVFR	Altitude AMSL	Remarks
Tai O	VFR and SVFR	Not above 1 000 ft	Over water west of Tai O.
Sham Shek	VFR	Not above 1 000 ft	
Pak Mong	VFR and SVFR	Not above 1 000 ft	
Tung Chung Bay	VFR	800 ft - 1 000 ft	
Freight Centre	VFR and SVFR	Not below 800 ft	Bounded by roundabouts to the NE and W of AFFC building and Lantau coast. Remain 1 000 m south of South Runway and have full length of runway in sight at all times.
Cathay City	VFR and SVFR	Not above 800 ft	Secondary hold when weather precludes use of Freight Centre hold. Remain 1 000 m south of south runway. Hold over water between Cathay City and Tung Chung Ferry Pier.

28 Helicopter Runway Crossing Procedures

28.1 ROUTES

28.1.1 Helicopters shall cross the runways via one of the two Runway Crossing Corridors – Runway 25 Crossing Corridor at the eastern boundary of the airport and Runway 07 Crossing Corridor at the western boundary of the airport (see chart AD2-VHHH-105). Helicopters are not normally permitted to cross over the airport. During parallel runway operations helicopters are not permitted to hold between the runways.

28.1.2 Runway 25 Crossing Corridor is a direct track between Holding Point ECHO and Abeam Cathay City, passing over RWY 25L/25R approach lights and east of Sky City.

28.1.3 Runway 07 Crossing Corridor is a corridor between Holding Point WHISKEY and Sha Lo Wan, passing over RWY 07L approach lights, west of HAECO hangar and immediately west of RWY 07R threshold. Helicopters overflying the airport should use the eastern part of the corridor and helicopters approaching or departing the airport should use the western part of the corridor.

28.1.4 The recommended altitude for the Runway Crossing Corridors is 800 ft AMSL for wake turbulence avoidance. Runway 07 Crossing Corridor is wide enough to permit helicopters approaching or departing the airport to manoeuvre and cross above the

glidepath profile of landing traffic.

- 28.1.5 ATC will normally issue a conditional crossing clearance with specific instructions to cross behind landing traffic. Pilots should be aware that there is normally a 5 mile spacing between arrivals. Once the relevant traffic has been visually identified, pilots should adjust their speed and track to ensure the crossing is completed with the minimum of delay after the landing aircraft has passed. Holding between the two runways is not permitted.
- 28.1.6 Because of the extra distance involved when crossing the north runway from the southern holding points, or crossing the south runway from the northern holding points, once a pilot has received a conditional crossing clearance and the relevant landing traffic has been positively identified, the helicopter may depart the holding point and position to cross behind the landing aircraft, but under no circumstances shall it proceed beyond the centreline of the airport until the landing aircraft has passed the applicable Crossing Corridor. (The centreline of the airport is taken as the spine of the Passenger Terminal Building and the north side of the HAECO hangar.)
- 28.1.7 Pilots unable to comply with these procedures, e.g. when operating with underslung loads, should provide adequate prior notification to ATC to facilitate alternative plans.

28.2 HELICOPTER HOLDING PROCEDURES FOR RUNWAY CROSSING

- 28.2.1 The following holding procedures shall be used by helicopters awaiting a runway crossing:

Location	VFR/SVFR	Altitude AMSL	Remarks
WHISKEY	VFR	Maximum 1 000 ft	Remain at least 1 000 m north of north runway
ECHO	VFR	Maximum 1 000 ft	Remain at least 1 000 m north of north runway
Sha Lo Wan	VFR	Not above 1 000 ft	Remain at least 1 000 m south of south runway
Cathay City	VFR	Not above 800 ft	Remain at least 1 000 m south of south runway
	SVFR	Not above 500 ft	
Tai O	VFR and SVFR	Not above 1 000 ft	
Pillar Point	VFR and SVFR	Not above 1 000 ft	
Sha Chau	VFR and SVFR	500 ft – 1 000 ft	

- 28.2.2 Helicopter holding patterns are right hand orbits with a speed restriction of not more than 70 KIAS.
- 28.2.3 Helicopters operating SVFR may be subject to extensive delay in waiting to cross the runways. Therefore runway crossings should be limited to flights of an urgent nature only. Other flights should consider re-routing and crossing the extended runway centre-line via Yam O – Brothers Point route. (When planning a SVFR flight operators should make allowances for possible holding delays and the alternative routing.)

29 Rejoining Procedures for Fixed Wing Aircraft

29.1 Three visual holding areas are established over prominent geographical features in the CTR to assist in the sequencing of VFR flights with other traffic. The holding areas are:

Location	Altitude AMSL	Runway in Use	Routeing
Green Island Left hand hold	Maximum 2 000 ft	RWY 25	For flights from the south
Soko Island Left hand hold	Maximum 2 000 ft	RWY 07	For flights from the south
Lung Kwu Chau/ Sha Chau Left hand hold	Maximum 1 500 ft Maximum 1 000 ft	RWY 07 RWY 25	For flights from the north

29.2 A visual holding pattern is established within the ATZ to assist in the sequencing of VFR flights with other traffic. Details of the holding pattern are:

Holding Pattern	Altitude AMSL	Runway in Use
ATZ Hold Left hand hold	1000 ft	RWY25
ATZ Hold Right hand hold		RWY 07

30. Procedures for Local Flights in Uncontrolled Airspace Reporting Areas (UCARAs)

30.1 GENERAL

30.1.1 Special areas have been defined to permit aircraft operations to take place under VFR. The associated procedures have been developed to allow such flying to take place without interference to aircraft operating in accordance with IFR and/or in the Hong Kong Aerodrome Traffic Zone and Control Zone. The six areas are designated as Uncontrolled Airspace Reporting Areas (UCARAs): Mirs Bay, North Border, New Town, Ninepins, Port Shelter and Tolo.

30.1.2 UCARA airspace is classified as Category G with an additional requirement for two-way radio communication.

30.2 LATERAL LIMITS

30.2.1 The lateral boundaries of the UCARAs are indicated on page AD2-102.

30.3 VERTICAL LIMITS

30.3.1 The vertical limits of the UCARAs are :

- | | |
|--|----------------------------|
| a) New Town, Port Shelter and Ninepins | Surface to 2 000 ft AMSL |
| b) Mirs Bay and Tolo | Surface to 3 000 ft AMSL |
| c) North Border | Surface to 2 000 ft AMSL * |

Note * Normally aircraft will be restricted to 1 000 ft AMSL or below. For operations above 1 000 ft prior permission from Hong Kong ATC is required which will be subject to co-ordination with Zhuhai ATC.

30.4 FLIGHT NOTIFICATION

30.4.1 Flight notification shall be submitted to Hong Kong Aerodrome Control in accordance with Regulations for Local Flights in Hong Kong (page AD2-17 para 1.1.4).

30.4.2 Aircraft or helicopters landing at Shek Kong aerodrome or any other site in UCARAs shall report their arrival to 'Hong Kong Information' immediately prior to landing. If no radio contact is made with 'Hong Kong Information' or if outside the notified hours of operation, pilots shall report to Hong Kong Aerodrome Control by telephone (tel no 2910 6822) as soon as possible after landing.

30.4.3 Pilots must note that if no landing report is received within 30 minutes of the estimated time of arrival, alerting action will be initiated by ATC.

30.5 COMMUNICATIONS

30.5.1 Pilots shall establish and maintain two-way communication with 'Hong Kong Information' on entering and when operating within UCARAs.

30.5.2 Pilots shall report their position and altitude as follows:

- a) When entering /leaving each UCARA;
- b) Every 15 minutes if no other communication have been made within that period.

30.5.3 When 'Hong Kong Information' is not available, pilots should broadcast their positions on frequency 121.0 MHz at appropriate intervals and when crossing UCARA boundaries, for the information of other aircraft in the area.

30.5.4 Flights in North Border have to be coordinated with Zhuhai ATC. Therefore pilots must advise Hong Kong Information at least 2 minutes prior to entering North Border when operating at 1 000 feet AMSL and below, or give at least 3 minutes notice if operating above 1 000 feet AMSL.

30.5.5 In order to enhance flight safety in the vicinity of the entry/exit routes to/from the Shek Kong Aerodrome Reporting Area (SKARA), pilots are to include in their initial transmission on leaving the SKARA, the name of the entry/exit route, as well as the UCARA they are entering.

30.6 RADIO COMMUNICATION FAILURE PROCEDURES

30.6.1 Fixed wing aircraft shall proceed to Shek Kong Aerodrome, carry out a standard joining procedure to the circuit keeping a good look-out whilst making all normal transmissions. Carry out a standard circuit to land, at all times exercising extreme caution with respect to other aircraft in the vicinity. After landing pilots are to taxi clear of the runway and shutdown. Pilots shall contact Hong Kong Aerodrome Control by telephone (tel. no. 2910 6822) as soon as possible after landing.

30.6.2 Helicopters shall land at a suitable helicopter landing site and pilots shall contact Hong Kong Aerodrome Control by telephone as soon as possible after landing.

31 Aerobatic Area

31.1 An Aerobatic Area is established within the northern portions of MIRS BAY and TOLO UCARAs and the TMA airspace immediately above them (see chart page AD2-102). The vertical limits of the Aerobatic Area are SFC – 3 500 ft AMSL.

31.2 The Aerobatic Area is available daily from 0900 – 1700 (local time), subject to VMC within the area and the aircraft having a serviceable transponder with Mode C. Aircraft shall remain below 3 000 ft AMSL and request clearance to climb to 3 500 ft AMSL from Hong Kong Information on frequency 121.0 MHz. Pilots are reminded that they are responsible for maintaining their own separation from other traffic operating in the UCARAs.

32 Flight Information Service

32.1 Hong Kong Flight Information Service provides a flight information service and an alerting service between 0900 local time and sunset, daily, to non-IFR flights operating within the UCARAs. Between sunset and 0859 local time, alerting service only is available. The radio call-sign is 'Hong Kong Information' and the frequency is 121.0 MHz primary and 122.4 MHz secondary.

32.2 It is emphasised that the service offered by Hong Kong Flight Information Service is an information service only and collision avoidance is entirely the responsibility of the pilot-in-command. Traffic information will normally be provided to an aircraft only when it reports entering a UCARA sector or makes a periodic 'ops normal' report. Aircraft already operating within a UCARA are expected to maintain their own traffic watch between 'ops normal' reports by monitoring the FIS frequency for the transmissions of other aircraft.

32.3 Outside of the hours of operation of Hong Kong Flight Information Service pilots should make 'blind' transmissions on the Hong Kong Information frequency and maintain a particularly good look-out for any deterioration of weather conditions.

33 Procedures for Entry and Exit to/from Shek Kong Aerodrome Reporting Area (SKARA)

33.1 Prior permission must be obtained from the appropriate military authority for any flight intending to operate within the Shek Kong Aerodrome Reporting Area (SKARA). (Details of the flight procedures applicable within the SKARA will be provided by the military authority.)

33.2 Aircraft shall enter or exit the Shek Kong Aerodrome Reporting Area (SKARA) via the following routes

Radio Callsign	Route	Co-ordinates (WGS 84)	Co-ordinates (UTM Grid)
Kadoorie Gap	SKARA to/from UCARA New Town	22 26 22N 114 07 23E	KK 039843 22 June 2017
Fire Station Gap	SKARA to/from UCARA New Town	22 28 14N 114 06 38E	KK 027878
Mai Po	SKARA to/from UCARA North Border	22 27 41N 114 03 09E	JK 973868
Pagoda	SKARA to/from CTR Tuen Mun Zone	22 27 48N 114 00 25E	JK 920872
Kam Tin Gap	SKARA to/from CTR Tuen Mun Zone	22 26 00N 114 02 57E	JK 963838

- 33.3 The SKARA reporting point 'PAGODA' is very close to the North Border boundary, therefore pilots exiting or entering the SKARA at this location should ensure they do not enter the North Border area without prior coordination.

| **(AD2-58 to AD2-74 reserved)**